



## **Cisco Catalyst Blade Switch 3040 for FSC Getting Started Guide**

### **INCLUDING LICENSE AND WARRANTY**

- 1** Introduction
- 2** Taking Out What You Need
- 3** BX600 System Architecture
- 4** Preparing to Install the Blade Switch in the BX600 System
- 5** Managing the Blade Switch
- 6** In Case of Difficulty
- 7** Obtaining Documentation
- 8** Documentation Feedback
- 9** Cisco Product Security Overview
- 10** Obtaining Technical Assistance
- 11** Obtaining Additional Publications and Information
- 12** Hardware Warranty Terms



# 1 Introduction

This guide provides instructions on how to install your Cisco Catalyst Blade Switch 3040 for FSC—referred to as the *blade switch*—in the Fujitsu Siemens PRIMERGY BX600 S2 system and to set up and configure it. The PRIMERGY BX600 S2—referred to as the *BX600 system*—supports up to four Ethernet blade switches in its blade bays.

This guide also covers management options and troubleshooting help for the blade switch.

For details on the numbers, types, and the location of the BX600 system slots, for additional information on the BX600 system, and for detailed port mapping information, see the BX600 setup and installation guide at <http://manuals.fujitsu-siemens.com/primergyservers.html>.

For additional installation and configuration information about the blade switch, see the Cisco Catalyst Blade Switch 3040 for FSC documentation on Cisco.com. For system requirements, important notes, limitations, open and resolved caveats, and last-minute documentation updates, see the release notes, also on Cisco.com.

When using the online publications, refer to the documents that match the Cisco IOS software version that is running on the blade switch. See the “Obtaining Documentation” section on page 1-24 for more information about the related publications.

For translations of the warnings that appear in this publication and all safety and handling warnings for this product, see the *Regulatory Compliance and Safety Information for the Cisco Catalyst Blade Switch 3040 for FSC* that accompanies this guide.

Before proceeding, read the release notes for the BX600 system. The release notes are available on the FSC support website at <http://support.fujitsu-siemens.com/com/support/index.html>.

## 2 Taking Out What You Need

These items ship with your blade switch:

- Console cable
- *Cisco Catalyst Blade Switch 3040 for FSC Getting Started Guide* (this book)
- *Regulatory Compliance and Safety Information for the Cisco Catalyst Blade Switch 3040 for FSC*
- Registration card

Follow these steps:

1. Unpack and remove the blade switch and the accessory kit from the shipping box.
2. Return the packing material to the shipping container, and save it for future use.

If you ordered the blade switches with the BX600 system, they are already installed. The unpacking procedure only applies if a blade switch is ordered separately. See the BX600 system documentation for the unpacking procedure for the BX600 system equipment.


# Cisco Gigabit Ethernet Blade Switch Description

Figure 1 shows the blade switch, which has these features:

- 10 internal Gigabit Ethernet 1000BASE-X ports
- 1 console port
- 2 external 10/100/1000BASE-T copper Gigabit Ethernet uplink ports
- 4 external small form-factor pluggable (SFP) module uplink ports that support 1000BASE-SX fiber and 10/100/1000BASE-T copper (only Cisco SFP modules are supported)

Each port has an associated LED. The associated BX600 system management blade controls a System Status/ID LED.

**Figure 1     The Catalyst Blade Switch 3040 for FSC**



1	Blade switch	6	Gigabit Ethernet port LEDs
2	Console port	7	SFP module ports
3	Console port LED	8	SFP module port LEDs
4	System Status/ID LED	9	Release latch
5	Gigabit Ethernet ports		

The blade switch is powered from the BX600 S2 system backplane, and temperature management is provided by the BX600 S2 system. The blade switch has no fan.


To set up the switch, you need a PC and an Ethernet (Category 5) straight-through cable (as shown) or a console cable (ships with the product).



# 3 BX600 System Architecture

The four BX600 system I/O blade slots are on the rear panel (see Figure 2). You can insert blade switches into the NET1, NET2, NET3, and NET4 I/O blade slots.

**Figure 2**     *Rear View of the BX600 System*




<b>1</b>	NET1 slot (with blade switch installed)	<b>5</b>	Rear panel of the BX600 system
<b>2</b>	NET2 slot	<b>6</b>	BX600 system management blade
<b>3</b>	NET3 slot	<b>7</b>	Advanced KVM <sup>1</sup> blade
<b>4</b>	NET4 slot		

1. KVM = Keyboard, video, mouse connection

Figure 3 shows the BX600 system management blade on the left and an optional advanced KVM blade on the right.

**Figure 3     BX600 System Management and Advanced KVM Blades**



1	RS-232 serial port	5	Failure indicator LED
2	Ethernet port	6	Advanced KVM blade Ethernet port
3	I2C connector <sup>1</sup>	7	KVM connector <sup>2</sup>
4	Green master indicator LED		

- 1. A proprietary Intelligent Platform Management Interface (IPMI) connector for Fujitsu Siemens Computers service applications
- 2. The KVM connector uses a special cable to connect a VGA monitor, a PS2 keyboard, and a PS2 mouse.

Table 1 describes the BX600 system management blade LEDs:

**Table 1      Management Blade LED Descriptions**

LED	Description
Ethernet port	Green: On shows link is up; blinking shows power is on. Amber: On shows LAN is active; blinking shows power is on.
Master (green)	On: The management blade is the master, responsible for managing the entire system. Off: The management blade is a slave—a standby or backup of the master management blade. Blinking: The management blade is in special mode.
Failure (amber)	On: If only one management blade is installed, it has failed. Off: This management blade is operating normally. Blinking: The management blade is running in power-on mode, that is, generating a heartbeat for the master/slave selection.



**Note** For more information about the master and failure management blade LEDs or the advanced KVM management blade, see the *PRIMERGY BX600 Basic Unit Operating Manual*.

Consider these requirements before you install your blade switch:

- The NET1 and NET2 slots are a pair. If the NET2 slot is used, the I/O blade in the NET2 slot must be the same type as the one in the NET1 slot.
- The NET3 and NET4 slots are a pair. If the NET4 slot is used, the I/O blade in the NET4 slot must be the same type as the one in the NET3 slot.
- If the blade switch is installed in the NET3 and NET4 slots, an Ethernet I/O module (daughter card) must be installed on the BX600 server.

For information about requirements for installing blades in the BX600 system or the components of the BX600 system, see the *PRIMERGY BX600 Basic Unit Operating Manual*.

## 4 Preparing to Install the Blade Switch in the BX600 System

Before you install the blade switch in the BX600 system, review the safety and compliance information:

- Review and become familiar with the safety guidelines in the *Regulatory Compliance and Safety Information for the Cisco Catalyst Blade Switch 3040 for FSC* that accompanies this guide.
- Review and become familiar with the BX600 system safety guidelines in the BX600 system documentation.
- Review and become familiar with any temperature, power, and grounding requirements specified in the BX600 system documentation.



### Warning

---

**Only trained and qualified personnel should be allowed to install, replace, or service this equipment.** Statement 1030

---



### Caution

---

To prevent electrostatic-discharge (ESD) damage when installing blade switches, follow your normal board and component handling procedures.

---



### Note

---

When you initially configure a blade switch, it should be in the same state as when it was shipped, that is, unconfigured and with no assigned default username and password.

---

When you install a blade switch, you do not need to power down the BX600 system.

## Overview of Steps for Installing and Configuring the Blade Switch

You can install and configure the blade switch by using either of two methods. In each, you start a terminal-emulation program on a PC. The terminal-emulation software—a PC application such as Hyperterminal or ProcommPlus—makes communication between the blade switch and your PC or terminal possible. The PC communicates with the blade switch either through its console port or through the console port of BX600 system management blade.

- To set up the blade switch through its console port, start with the next section, “Installing the Blade Switch in the BX600 System.”
- To set up the blade switch through the BX600 system management blade, first connect it to a PC to run the terminal emulation program and to interact with the console menu. Do this before you install the blade switch into the BX600 system. Start with the “Connecting through the BX600 System Management Blade” section on page 13.



# Installing the Blade Switch in the BX600 System

Follow these steps to install the blade switch in the BX600 system:

- 
- Step 1** Obtain and make note of this information from your system administrator before you begin the blade switch installation:
- Switch IP address
  - Subnet mask (IP netmask)
  - Default gateway (router)
  - Enable secret password (encrypted)
  - Enable password (not encrypted)
  - Telnet password
  - SNMP community strings (optional)
- Step 2** Touch the blade switch static-protective package to unpainted metal on the BX600 system for at least 2 seconds.
- Step 3** Remove any dummy blade from the slot.



---

**Caution**


Keep dummy blades for future use. If you remove the blade switch and do not replace it with another one, you must reinstall a dummy blade in that slot.

---

- Step 4** Remove the blade switch from its static-protective package.
- Step 5** Select the I/O slot in which to install the blade switch. Follow the installation requirements listed in the “BX600 System Architecture” section on page 5.

**Step 6** Ensure that the release latch on the blade switch is in the open position. (See Figure 4.)

**Figure 4**     *Open the Blade Switch Release Latch*




1	Release latch in open position
---	--------------------------------

**Step 7** Slide the blade switch into the slot until it stops.

**Step 8** Push the release latch on the front of the blade switch toward the right and into the closed position.

Figure 5 shows the blade switch being inserted into the BX600 system.

**Figure 5**     *Inserting the Blade Switch into the BX600 System*



<b>1</b>	Blade switch	<b>3</b>	BX600 system
<b>2</b>	Release latch		


**Step 9** If you are setting up the blade switch through the its console port, go to the “Connecting through the Blade Switch Console Port” section on page 12. If you are setting it up through the BX600 system management blade, go to Step 6 in the “Connecting through the BX600 System Management Blade” section on page 13.

## Connecting through the Blade Switch Console Port

Follow these steps to set up the blade switch by connecting it to a PC through its console port:

- Step 1** Connect one end of the console cable to the blade switch console port. Connect the other end of the cable to the serial port of a PC. (See Figure 6.)

**Figure 6** *Connecting through the Blade Switch Console Port*



190185


- Step 2** Start the terminal emulation session so you can see the output display from the power-on self-test (POST).
- Step 3** On the PC terminal emulation program:
- a. Set the data format to 8 data bits, 1 stop bit, and no parity.
  - b. Set the terminal emulation speed to 9600 baud.
  - c. Set the flow control to None.
- Step 4** Go to the “Waiting for POST to Complete” section on page 16 to finish configuring the blade switch.
- 

## Connecting through the BX600 System Management Blade

Follow these steps to set up the blade switch by connecting to a PC through the BX600 system management blade console port:

- 
- Step 1** Connect one end of a DB9 null-modem or a crossover cable to the RS-232 console serial port of the associated management blade. Connect the other end of the cable to the RS-232 console serial port of the PC. (See Figure 7.)

**Figure 7**     *Connecting through the BX600 System Management Blade*



190186

**Step 2**    On the PC terminal emulation program:

- a. Set the data format to 8 data bits, 1 stop bit, and no parity.
- b. Set the terminal emulation speed to 115200 baud.
- c. Set Flow Control to none.
- d. Under Properties, select VT100 for Emulation mode.
- e. Select Terminal keys for Function, Arrow, and Ctrl keys. Make sure that you select Terminal keys not Windows keys.

**Step 3** On the console monitor, the management blade application displays a login screen. Log in by using these defaults:  
username **root**  
password **root**

The management blade Console Main menu appears.



---

**Note** If the BX600 system is already configured, obtain the management blade username and password from the system administrator. If you use *root* for the username and password, you must change them later. See the BX600 system documentation for more information.

---

**Step 4** To power on the BX600 system, use these menu choices in the Console Main menu:

- a. Enter 1 (Management Agent). The Management Agent menu appears.
- b. Enter 3 (System Information). The System Information menu appears.
- c. Enter 2 (Power Supply). The Power Supply menu appears.
- d. Enter 1 (Power Control). The Power Control menu appears.
- e. Enter 2 to power on the BX600 system.
- f. Enter 0 at each menu to return to the main menu.



---

**Note** The management blade console menu uses a hot key to return to a previous menu. The default is set to **Ctrl-Q**. For some terminal emulation programs, **Ctrl-Q** might not work. You can reset the hot key in the Console Redirection Table menu. Choose a character from A-Z, excluding M. The hot key to exit console redirection and return to the previous mode is then Ctrl + the character you have set. For more information, see the BX600 system documentation.

---

**Step 5** Install the blade switch by following the instructions in the “Installing the Blade Switch in the BX600 System” section on page 9, and then return to this section.

**Step 6** After you have installed the blade switch in the BX600 system, wait for the blade switch port 11x LED to blink green before you continue.

**Step 7** Enter 3 (Console Redirection) on the main menu to open the Console Redirection Table menu.

**Step 8** Enter 2 (Console Redirect Switch Blade) in the Console Redirection Table menu to redirect the console to the blade switch. The Console Redirection Switch Blade menu appears.

**Step 9** Enter 1 if you are configuring the blade switch in the NET1 slot, 2 if you are configuring the blade switch in the NET2 slot, and so on.

**Step 10** Go to “Waiting for POST to Complete” section on page 16 to finish configuring the blade switch.

---

If the blade switch is already installed and powered up when you use the BX600 system management blade console menu, you must reboot the switch to display the system configuration dialog:

1. Enter **enable** at the user EXEC (*Switch>*) prompt, then enter **reload** at the privileged EXEC mode (*Switch#*) prompt.
2. Follow the instructions in the next section, “Waiting for POST to Complete.”

## Waiting for POST to Complete

Follow these steps:

---

**Step 1** Wait several minutes for the blade switch to complete the POST.

**Step 2** The POST is complete when the System Status/ID LED is off and the Console LED is solid green or amber.

If the blade switch fails POST because of a misconfiguration or error, the System Status/ID LED blinks green and the Console LED is off.



**Note** POST errors are usually fatal. Call Cisco Customer Support immediately if your blade switch fails POST.

---

**Step 3** Wait for the blade switch to complete flash initialization. When you see the prompt **Press Return to Get Started!**, wait for any interface status information output to finish its appearance, then press **Return** or **Enter**.

**Step 4** Make sure that the System Status/ID LED is off and that the Console LED is green or amber. The blade switch is now operating properly.

**Step 5** See the “Completing the Initial Configuration” section on page 17 for instructions on setting up and initially configuring the blade switch.

---



## Completing the Initial Configuration

Follow these steps to complete the setup program and to create an initial configuration.



### Note

For information about how to automatically configure the blade switch, see the “Assigning the Switch IP Address and Default Gateway” chapter in the blade switch configuration guide.

**Step 1** After you have pressed **Enter** or **Return** after the prompt to start the system configuration dialog, enter **yes** at these prompts:

```
Would you like to terminate autoinstall? [yes]: yes  
--- System Configuration Dialog ---  
Continue with configuration dialog? [yes/no]: yes
```

At any point you may enter a question mark '?' for help.  
Use ctrl-c to abort configuration dialog at any prompt.  
Default settings are in square brackets '['].

Basic management setup configures only enough connectivity  
for management of the system, extended setup will ask you  
to configure each interface on the system

```
Would you like to enter basic management setup? [yes/no]: yes
```

**Step 2** Enter a hostname for the blade switch after the prompt, and press **Return**.

The hostname is limited to 20 characters. Do not use *-n*, where n is a number, as the last character in a host name for any blade switch.

**Step 3** Enter an enable secret password, and press **Return**.

The password can be from 1 to 25 alphanumeric characters, can start with a number, is case sensitive, allows spaces, but ignores leading spaces. The secret password is encrypted, and the enable password is in plain text.

**Step 4** Enter an enable password, and press **Return**.

**Step 5** Enter a virtual terminal (Telnet) password, and press **Return**.

The password can be from 1 to 25 alphanumeric characters, is case sensitive, allows spaces, but ignores leading spaces.

**Step 6** (Optional) Configure Simple Network Management Protocol (SNMP) by responding to the prompts.

To configure SNMP later, press **Return** (which applies the default of no). If you accept the default, you can configure SNMP later through the CLI.

```
Configure SNMP Network Management? [no]:
```

To configure SNMP now, enter **yes**.

```
Configure SNMP Network Management? [no]: yes  
Community string [public]: public
```

The Current interface summary displays.

**Step 7** Enter **vlan1** for the interface name at this prompt:

```
Enter interface name used to connect to the management network from the above  
interface summary.
```

**Step 8** To configure the interface, enter **Yes** after the prompt, and then enter the blade switch IP address and subnet mask. Press **Return**.

The IP address and subnet mask shown here are examples:

```
Configuring interface Vlan1:  
Figure IP on this interface? [yes]: Yes  
IP address for this interface [10.0.0.1]: 10.0.0.1  
Subnet mask for this interface [255.255.255.0] : 255.255.255.0  
Class A network is 10.0.0.1, 21 subnet bits; mask is /21
```

**Step 9** Enter **no** when the prompt asks you if you would like to enable the blade switch as a cluster command switch. This is a standalone blade switch.

```
Would you like to enable as a cluster command switch? [yes/no]: no
```



---

**Note** Clustering is not supported on the Cisco Catalyst Blade Switch 3040 for FSC.

---

You have now completed the initial configuration. An example of the output is shown here:

The following configuration command script was created:

```
hostname switch1  
enable secret 5 $1$cagJ$e4LP91PNazfdADoNAZm6y0  
enable password enable_password  
line vty 0 15  
password terminal-password  
snmp-server community public  
!  
!  
interface Vlan1
```

```
no shutdown
ip address 10.0.0.1 255.255.255.0
!
interface GigabitEthernet0/1
!
interface GigabitEthernet0/2

. . . (output truncated)

interface GigabitEthernet0/16
!
end
```

**Step 10** These choices appear. Enter **2**, and then press **Return**.

[0] Go to the IOS command prompt without saving this config.

[1] Return back to the setup without saving this config.

[2] Save this configuration to nvram and exit.

If you want to save the configuration and use it the next time the switch reboots, save it in NVRAM by selecting option 2.

Enter your selection [2]:**2**

Make your selection, and press **Return**.

**Step 11** If you plan to set up more than one blade switch, enter **Ctrl-Q** to return to the Console Redirect Switch Blade menu, and choose the next blade switch. When you have set up all of the blade switches, enter **0** on the Console Redirect Switch Blade menu to return to the management blade Console Main menu. This re-enables the blade switch console port.

**Step 12** Disconnect the BX600 system serial port or the blade switch console port from the PC. See the “Managing the Blade Switch” section on page 20 for information about configuring and managing the blade switch.

If you need to rerun the system configuration dialog, see the “Resetting the Switch Configuration” section on page 24.

---

# 5 Managing the Blade Switch


After you complete the initial configuration, use the device manager or other management options described in this section for further configuration.

## Using the Device Manager

The simplest way to manage the blade switch is by using the device manager that is in its memory. This is a web interface that offers quick configuration and monitoring. You can access the device manager from anywhere in your network through a web browser.

Follow these steps:

- Step 1 Launch a web browser on your PC or workstation.
- Step 2 Enter the blade switch IP address in the web browser, and press **Enter**. The device manager page appears.




**Step 3** Use the device manager to perform basic blade switch configuration and monitoring. Refer to the device manager online help for more information.

## Using the Management Blade Web Interface

You can monitor and manage the blade switches through the BX600 system web interface. Follow these steps:

1. Launch a web browser on your PC or workstation.
2. Enter the BX600 system IP address in the web browser, and press **Enter**. The web interface appears.
3. Click **Switch Blade 1**, **Switch Blade 2**, and so on to see the information for a specific blade switch.



You can do these tasks:

- In the Located LED field, choose **on** or **off**, and click **Apply** to locate the blade switch.
- Under Network Setting, click the URL Address field to open the blade switch web interface.

- To reset the IP address, the subnet mask, or the gateway address, enter the new settings in the appropriate field, and click **Apply** and **Reload**. These settings apply only to VLAN 1. If you are using a management VLAN other than VLAN 1, the applied settings might not produce the intended results. See the BX600 system documentation for more information about setting these fields.
- To enable polling, click **Enable** and **Apply**. The default polling period is 300 seconds. To begin polling immediately, after you click **Enable** and **Apply**, click **Reset** under Reset the Switch Blade. Before you manage the blade switch from its console port, we recommend that you disable polling.
- If you configured a password for the blade switch through the management blade console menu, you must enter that password in the Set Password for Polling Account field, and click **Enable**. Otherwise, leave this field blank.
- Click **Reset** to reset the blade switch.

For more information about using this interface, see the *PRIMERGY BX Blade Server Systems RemoteView Management Blade User Interface Description*.

## Using the Command-Line Interface

You can enter Cisco IOS commands and parameters through the CLI. Access the CLI either by connecting your PC directly to the blade switch console port or through a Telnet session from a remote PC or workstation.

Follow these steps:

- 
- Step 1** Connect the supplied console cable to the standard 9-pin serial port on the PC. Connect the other end of the cable to the console port on the blade switch.
  - Step 2** Start a terminal-emulation program on the PC.
  - Step 3** Configure the PC terminal emulation software for:
    - 9600 baud
    - 8 data bits
    - No parity
    - 1 stop bit
    - No flow control
  - Step 4** Use the CLI to enter commands to configure the blade switch. See the blade switch software configuration guide and the blade switch command reference for more information.
-

## Other Management Options

You can use SNMP management applications to configure and to manage the blade switch. You also can manage it from an SNMP-compatible workstation that is running platforms such as HP OpenView or SunNet Manager.

See the “Accessing Help Online” section on page 24 for a list of supporting documentation.

## 6 In Case of Difficulty

If you experience difficulty, help is available in this section and on Cisco.com. This section includes initial setup troubleshooting, how to reset the switch, how to access help online, and where to find more information.

### Troubleshooting the Initial Configuration Setup

If you have problems running the system configuration dialog:

- |   |   |
|---|---|
| • Did you verify that POST ran successfully before running the system configuration dialog? | POST errors are usually fatal. Call Cisco Customer Support immediately if your blade switch fails POST.   |
| • Did the blade switch not power on?  | The blade switch power is controlled by the BX600 system. If the blade switch does not power on, see the BX600 system documentation for more information. |
| • Did you lock yourself out and forget your password?                                       | See the “Recovering from a Lost or Forgotten Password” section in the “Troubleshooting” appendix of the blade switch software configuration guide.        |

## Resetting the Switch Configuration

This section describes how to reset the blade switch configuration by rerunning the system configuration dialog. These are reasons why you might want to reset the blade switch:

- You installed the blade switch in your network and cannot connect to it because you assigned the wrong IP address.
- You want to clear all configuration from the blade switch and assign a new IP address.

To reset the switch and cause the system configuration dialog to display, you must first delete the `config.text` file in your directory. Follow these steps:

---

**Step 1** At the switch user EXEC prompt, `switch>`, enter **enable** to enable the privileged EXEC mode.

**Step 2** At the privileged EXEC prompt, `switch#`, enter **write erase**, and press **Return** or **Enter**.



---

**Caution** Entering **write-erase** deletes the configuration and reboots the switch.

---

**Step 3** At the privileged EXEC prompt, `switch#`, enter **reload**, and press **Return** or **Enter**.

**Step 4** If you have not made changes to the configuration, the prompt asks if you want to proceed with reload. Enter **yes**.

If you have made changes to the configuration, the prompt asks if you want to save it. Enter **no**.

---

The switch displays the prompt to start the system configuration dialog. See the “Completing the Initial Configuration” section on page 17 to re-enter the configuration information and set up your switch.

## Accessing Help Online

First look for a solution to your problem in the troubleshooting section of the *Cisco Catalyst Blade Switch 3040 for FSC Hardware Installation Guide* or the *Cisco Catalyst Blade Switch 3040 for FSC Software Configuration Guide* on Cisco.com. You can also access the Cisco Technical Support and Documentation website for a list of known hardware problems and extensive troubleshooting documentation, including:

- Factory defaults and password recovery
- Recovery from corrupted or missing software
- Blade switch port problems



- Network interface cards
- Troubleshooting tools
- Field notices and security advisories

Follow these steps:

1. Open your browser, and go to <http://www.cisco.com/>.
2. Click **Technical Support and Documentation**.
3. Click **Tools and Resources**.
4. Under Jump to, click **Troubleshooting**.
5. Click the subject that addresses the problem that you are experiencing.

## For More Information

For more information about the blade switch, see these documents on Cisco.com:

- *Cisco Catalyst Blade Switch 3040 for FSC Hardware Installation Guide* (not orderable, but available on Cisco.com). This guide provides complete hardware descriptions and detailed installation procedures.
- *Regulatory Compliance and Safety Information for the Cisco Catalyst Blade Switch 3040 for FSC* (order number DOC-7817607=). This guide contains agency approvals, compliance information, and translated warning statements.
- *Release Notes for the Cisco Catalyst Blade Switch 3040 for FSC* (not orderable but available on Cisco.com)
- *Cisco Catalyst Blade Switch 3040 for FSC Software Configuration Guide* (not orderable, but available on Cisco.com). This guide provides a product overview and detailed descriptions and procedures for the blade switch software features.
- *Cisco Catalyst Blade Switch 3040 for FSC Command Reference* (not orderable, but available on Cisco.com). This reference provides detailed descriptions of the Cisco IOS commands specifically created or modified for the blade switch.
- *Cisco Catalyst Blade Switch 3040 for FSC System Message Guide* (not orderable, but available on Cisco.com). This guide provides descriptions of the system messages specifically created or modified for the blade switch.

## 7 Obtaining Documentation

Cisco documentation and additional literature are available on Cisco.com. Cisco also provides several ways to obtain technical assistance and other technical resources. These sections explain how to obtain technical information from Cisco Systems.

### Cisco.com

You can access the most current Cisco documentation at this URL:

<http://www.cisco.com/techsupport>

You can access the Cisco website at this URL:

<http://www.cisco.com>

You can access international Cisco websites at this URL:

[http://www.cisco.com/public/countries\\_languages.shtml](http://www.cisco.com/public/countries_languages.shtml)

### Product Documentation DVD

The Product Documentation DVD is a comprehensive library of technical product documentation on a portable medium. The DVD enables you to access multiple versions of installation, configuration, and command guides for Cisco hardware and software products. With the DVD, you have access to the same HTML documentation that is found on the Cisco website without being connected to the Internet. Certain products also have PDF versions of the documentation available.

The Product Documentation DVD is available as a single unit or as a subscription. Registered Cisco.com users (Cisco direct customers) can order a Product Documentation DVD (product number DOC-DOCDVD= or DOC-DOCDVD=SUB) from Cisco Marketplace at this URL:

<http://www.cisco.com/go/marketplace/>

### Ordering Documentation

Registered Cisco.com users may order Cisco documentation at the Product Documentation Store in the Cisco Marketplace at this URL:

<http://www.cisco.com/go/marketplace/>

Nonregistered Cisco.com users can order technical documentation from 8:00 a.m. to 5:00 p.m. (0800 to 1700) PDT by calling 1 866 463-3487 in the United States and Canada, or elsewhere by calling 011 408 519-5055. You can also order documentation by e-mail at [tech-doc-store-mkpl@external.cisco.com](mailto:tech-doc-store-mkpl@external.cisco.com) or by fax at 1 408 519-5001 in the United States and Canada, or elsewhere at 011 408 519-5001.

## 8 Documentation Feedback

You can rate and provide feedback about Cisco technical documents by completing the online feedback form that appears with the technical documents on Cisco.com.

You can submit comments about Cisco documentation by using the response card (if present) behind the front cover of your document or by writing to the following address:

Cisco Systems  
Attn: Customer Document Ordering  
170 West Tasman Drive  
San Jose, CA 95134-9883

We appreciate your comments.

## 9 Cisco Product Security Overview

Cisco provides a free online Security Vulnerability Policy portal at this URL:

[http://www.cisco.com/en/US/products/products\\_security\\_vulnerability\\_policy.html](http://www.cisco.com/en/US/products/products_security_vulnerability_policy.html)

From this site, you will find information about how to:

- Report security vulnerabilities in Cisco products.
- Obtain assistance with security incidents that involve Cisco products.
- Register to receive security information from Cisco.

A current list of security advisories, security notices, and security responses for Cisco products is available at this URL:

<http://www.cisco.com/go/psirt>

To see security advisories, security notices, and security responses as they are updated in real time, you can subscribe to the Product Security Incident Response Team Really Simple Syndication (PSIRT RSS) feed. Information about how to subscribe to the PSIRT RSS feed is found at this URL:

[http://www.cisco.com/en/US/products/products\\_psirt\\_rss\\_feed.html](http://www.cisco.com/en/US/products/products_psirt_rss_feed.html)

## Reporting Security Problems in Cisco Products

Cisco is committed to delivering secure products. We test our products internally before we release them, and we strive to correct all vulnerabilities quickly. If you think that you have identified a vulnerability in a Cisco product, contact PSIRT:

- For Emergencies only—[security-alert@cisco.com](mailto:security-alert@cisco.com)

An emergency is either a condition in which a system is under active attack or a condition for which a severe and urgent security vulnerability should be reported. All other conditions are considered nonemergencies.

- For Nonemergencies—[psirt@cisco.com](mailto:psirt@cisco.com)

In an emergency, you can also reach PSIRT by telephone:

- 1 877 228-7302
- 1 408 525-6532



### Tip

---

We encourage you to use Pretty Good Privacy (PGP) or a compatible product (for example, GnuPG) to encrypt any sensitive information that you send to Cisco. PSIRT can work with information that has been encrypted with PGP versions 2.x through 9.x.

Never use a revoked or an expired encryption key. The correct public key to use in your correspondence with PSIRT is the one linked in the Contact Summary section of the Security Vulnerability Policy page at this URL:

[http://www.cisco.com/en/US/products/products\\_security\\_vulnerability\\_policy.html](http://www.cisco.com/en/US/products/products_security_vulnerability_policy.html)

The link on this page has the current PGP key ID in use.

If you do not have or use PGP, contact PSIRT at the aforementioned e-mail addresses or phone numbers before sending any sensitive material to find other means of encrypting the data.

---

## 10 Obtaining Technical Assistance

Cisco Technical Support provides 24-hour-a-day award-winning technical assistance. The Cisco Technical Support & Documentation website on [Cisco.com](http://Cisco.com) features extensive online support resources. In addition, if you have a valid Cisco service contract, Cisco Technical Assistance Center (TAC) engineers provide telephone support. If you do not have a valid Cisco service contract, contact your reseller.

## Cisco Technical Support & Documentation Website

The Cisco Technical Support & Documentation website provides online documents and tools for troubleshooting and resolving technical issues with Cisco products and technologies. The website is available 24 hours a day, at this URL:

<http://www.cisco.com/techsupport>

Access to all tools on the Cisco Technical Support & Documentation website requires a Cisco.com user ID and password. If you have a valid service contract but do not have a user ID or password, you can register at this URL:

<http://tools.cisco.com/RPF/register/register.do>



### Note

---

Use the Cisco Product Identification (CPI) tool to locate your product serial number before submitting a web or phone request for service. You can access the CPI tool from the Cisco Technical Support & Documentation website by clicking the **Tools & Resources** link under Documentation & Tools. Choose **Cisco Product Identification Tool** from the Alphabetical Index drop-down list, or click the **Cisco Product Identification Tool** link under Alerts & RMAs. The CPI tool offers three search options: by product ID or model name; by tree view; or for certain products, by copying and pasting **show** command output. Search results show an illustration of your product with the serial number label location highlighted. Locate the serial number label on your product and record the information before placing a service call.

---

## Submitting a Service Request

Using the online TAC Service Request Tool is the fastest way to open S3 and S4 service requests. (S3 and S4 service requests are those in which your network is minimally impaired or for which you require product information.) After you describe your situation, the TAC Service Request Tool provides recommended solutions. If your issue is not resolved using the recommended resources, your service request is assigned to a Cisco engineer. The TAC Service Request Tool is located at this URL:

<http://www.cisco.com/techsupport/servicerequest>

For S1 or S2 service requests, or if you do not have Internet access, contact the Cisco TAC by telephone. (S1 or S2 service requests are those in which your production network is down or severely degraded.) Cisco engineers are assigned immediately to S1 and S2 service requests to help keep your business operations running smoothly.

To open a service request by telephone, use one of the following numbers:

Asia-Pacific: +61 2 8446 7411 (Australia: 1 800 805 227)

EMEA: +32 2 704 55 55

USA: 1 800 553-2447

For a complete list of Cisco TAC contacts, go to this URL:

<http://www.cisco.com/techsupport/contacts>

## Definitions of Service Request Severity

To ensure that all service requests are reported in a standard format, Cisco has established severity definitions.

**Severity 1 (S1)**—An existing network is down, or there is a critical impact to your business operations. You and Cisco will commit all necessary resources around the clock to resolve the situation.

**Severity 2 (S2)**—Operation of an existing network is severely degraded, or significant aspects of your business operations are negatively affected by inadequate performance of Cisco products. You and Cisco will commit full-time resources during normal business hours to resolve the situation.

**Severity 3 (S3)**—Operational performance of the network is impaired, while most business operations remain functional. You and Cisco will commit resources during normal business hours to restore service to satisfactory levels.

**Severity 4 (S4)**—You require information or assistance with Cisco product capabilities, installation, or configuration. There is little or no effect on your business operations.

## 11 Obtaining Additional Publications and Information

Information about Cisco products, technologies, and network solutions is available from various online and printed sources.

- The *Cisco Product Quick Reference Guide* is a handy, compact reference tool that includes brief product overviews, key features, sample part numbers, and abbreviated technical specifications for many Cisco products that are sold through channel partners. It is updated twice a year and includes the latest Cisco offerings. To order and find out more about the Cisco Product Quick Reference Guide, go to this URL:

<http://www.cisco.com/go/guide>

- Cisco Marketplace provides a variety of Cisco books, reference guides, documentation, and logo merchandise. Visit Cisco Marketplace, the company store, at this URL:

<http://www.cisco.com/go/marketplace/>

- *Cisco Press* publishes a wide range of general networking, training and certification titles. Both new and experienced users will benefit from these publications. For current Cisco Press titles and other information, go to Cisco Press at this URL:

<http://www.ciscopress.com>

- *Packet* magazine is the Cisco Systems technical user magazine for maximizing Internet and networking investments. Each quarter, Packet delivers coverage of the latest industry trends, technology breakthroughs, and Cisco products and solutions, as well as network deployment and troubleshooting tips, configuration examples, customer case studies, certification and training information, and links to scores of in-depth online resources. You can access Packet magazine at this URL:

<http://www.cisco.com/packet>

- *iQ Magazine* is the quarterly publication from Cisco Systems designed to help growing companies learn how they can use technology to increase revenue, streamline their business, and expand services. The publication identifies the challenges facing these companies and the technologies to help solve them, using real-world case studies and business strategies to help readers make sound technology investment decisions. You can access iQ Magazine at this URL:

<http://www.cisco.com/go/iqmagazine>

or view the digital edition at this URL:

<http://ciscoiq.texterity.com/ciscoiq/sample/>

- *Internet Protocol Journal* is a quarterly journal published by Cisco Systems for engineering professionals involved in designing, developing, and operating public and private internets and intranets. You can access the Internet Protocol Journal at this URL:

<http://www.cisco.com/ipj>

- Networking products offered by Cisco Systems, as well as customer support services, can be obtained at this URL:

<http://www.cisco.com/en/US/products/index.html>

- Networking Professionals Connection is an interactive website for networking professionals to share questions, suggestions, and information about networking products and technologies with Cisco experts and other networking professionals. Join a discussion at this URL:

<http://www.cisco.com/discuss/networking>

- World-class networking training is available from Cisco. You can view current offerings at this URL:

<http://www.cisco.com/en/US/learning/index.html>

# 12 Hardware Warranty Terms

This section describes the warranty terms for the blade switch.

## FSC Hardware Warranty Terms



### Note

---

Important Note about Your Warranty: The limited warranty below reflects the extent of the Cisco warranty for the Cisco Catalyst Blade Switch 3040 for FSC. If you purchased this product from FSC, FSC might provide an additional warranty that is different than the limited warranty terms below. See the Product Information Guide included with your FSC branded server product for the applicable warranty information. This additional warranty is provided by FSC and not by Cisco; please see your authorized FSC representative for any questions or claims related to this warranty. Cisco disclaims any warranty other than as specifically provided below.

---

## Cisco 90-Day Limited Hardware Warranty Terms

There are special terms applicable to your hardware warranty and various services that you can use during the warranty period. Your formal Warranty Statement, including the warranties and license agreements applicable to Cisco software, is available on Cisco.com. Follow these steps to access and download the *Cisco Information Packet* and your warranty and license agreements from Cisco.com.

1. Launch your browser, and go to this URL:  
[http://www.cisco.com/univercd/cc/td/doc/es\\_inpk/cetrans.htm](http://www.cisco.com/univercd/cc/td/doc/es_inpk/cetrans.htm)  
The Warranties and License Agreements page appears.
2. To read the *Cisco Information Packet*, follow these steps:
  - a. Click the **Information Packet Number** field, and make sure that the part number 78-5235-03B0 is highlighted.
  - b. Select the language in which you would like to read the document.
  - c. Click **Go**.

The Cisco Limited Warranty and Software License page from the Information Packet appears.



- d. Read the document online, or click the **PDF** icon to download and print the document in Adobe Portable Document Format (PDF).

**Note**

---

You must have Adobe Acrobat Reader to view and print PDF files. You can download the reader from Adobe's website: <http://www.adobe.com>

---

3. To read translated and localized warranty information about your product, follow these steps:
  - a. Enter this part number in the Warranty Document Number field:  
78-5236-01C0
  - b. Select the language in which you would like to read the document.
  - c. Click **Go**.  
The Cisco warranty page appears.
  - d. Review the document online, or click the **PDF** icon to download and print the document in Adobe Portable Document Format (PDF).

You can also contact the Cisco service and support website for assistance:

[http://www.cisco.com/public/Support\\_root.shtml](http://www.cisco.com/public/Support_root.shtml).

## **Duration of Hardware Warranty**

Ninety (90) days.

## **Replacement, Repair, or Refund Policy for Hardware**

Cisco or its service center will use commercially reasonable efforts to ship a replacement part within ten (10) working days after receipt of a Return Materials Authorization (RMA) request. Actual delivery times can vary, depending on the customer location.

Cisco reserves the right to refund the purchase price as its exclusive warranty remedy.

**To Receive a Return Materials Authorization (RMA) Number**

Contact the company from whom you purchased the product. If you purchased the product directly from Cisco, contact your Cisco Sales and Service Representative.

Complete the information below, and keep it for reference:

Company product purchased from	
Company telephone number	
Product model number	
Product serial number	
Maintenance contract number	



## CISCO SYSTEMS



### Corporate Headquarters

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA

[www.cisco.com](http://www.cisco.com)  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 526-4100

### European Headquarters

Cisco Systems International BV  
Haarlerbergpark  
Haarlerbergweg 13-19  
1101 CH Amsterdam  
The Netherlands

[www-europe.cisco.com](http://www-europe.cisco.com)  
Tel: 31 0 20 357 1000  
Fax: 31 0 20 357 1100

### Americas Headquarters

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA

[www.cisco.com](http://www.cisco.com)  
Tel: 408 526-7660  
Fax: 408 527-0883

### Asia Pacific Headquarters

Cisco Systems, Inc.  
168 Robinson Road  
#28-01 Capital Tower  
Singapore 068912

[www.cisco.com](http://www.cisco.com)  
Tel: +65 6317 7777  
Fax: +65 6317 7799

**Cisco Systems has more than 200 offices in the following countries. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices)**

Argentina • Australia • Austria • Belgium • Brazil • Bulgaria • Canada • Chile • China PRC • Colombia • Costa Rica • Croatia • Cyprus • Czech Republic • Denmark • Dubai, UAE  
Finland • France • Germany • Greece • Hong Kong SAR • Hungary • India • Indonesia • Ireland • Israel • Italy • Japan • Korea • Luxembourg • Malaysia • Mexico  
The Netherlands • New Zealand • Norway • Peru • Philippines • Poland • Portugal • Puerto Rico • Romania • Russia • Saudi Arabia • Scotland • Singapore  
Slovakia • Slovenia • South Africa • Spain • Sweden • Switzerland • Taiwan • Thailand • Turkey • Ukraine • United Kingdom • United States • Venezuela • Vietnam • Zimbabwe

CCSP, CCVP, the Cisco Square Bridge logo, Follow Me Browsing, and StackWise are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and iQuick Study are service marks of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, FormShare, GigaDrive, GigaStack, HomeLink, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, LightStream, Linksys, MeetingPlace, MGX, the Networkers logo, Networking Academy, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, ProConnect, RateMUX, ScriptShare, SlideCast, SMARTnet, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0601R)

© 2006 Cisco Systems, Inc. All rights reserved.

Printed in the USA on recycled paper containing 10% postconsumer waste.



## Information on this document

On April 1, 2009, Fujitsu became the sole owner of Fujitsu Siemens Computers. This new subsidiary of Fujitsu has been renamed Fujitsu Technology Solutions.

This document from the document archive refers to a product version which was released a considerable time ago or which is no longer marketed.

Please note that all company references and copyrights in this document have been legally transferred to Fujitsu Technology Solutions.

Contact and support addresses will now be offered by Fujitsu Technology Solutions and have the format ...@[ts.fujitsu.com](mailto:ts.fujitsu.com).

The Internet pages of Fujitsu Technology Solutions are available at <http://ts.fujitsu.com/>...

and the user documentation at <http://manuals.ts.fujitsu.com>.

Copyright Fujitsu Technology Solutions, 2009

## Hinweise zum vorliegenden Dokument

Zum 1. April 2009 ist Fujitsu Siemens Computers in den alleinigen Besitz von Fujitsu übergegangen. Diese neue Tochtergesellschaft von Fujitsu trägt seitdem den Namen Fujitsu Technology Solutions.

Das vorliegende Dokument aus dem Dokumentenarchiv bezieht sich auf eine bereits vor längerer Zeit freigegebene oder nicht mehr im Vertrieb befindliche Produktversion.

Bitte beachten Sie, dass alle Firmenbezüge und Copyrights im vorliegenden Dokument rechtlich auf Fujitsu Technology Solutions übergegangen sind.

Kontakt- und Supportadressen werden nun von Fujitsu Technology Solutions angeboten und haben die Form ...@[ts.fujitsu.com](mailto:ts.fujitsu.com).

Die Internetseiten von Fujitsu Technology Solutions finden Sie unter <http://de.ts.fujitsu.com/>..., und unter <http://manuals.ts.fujitsu.com> finden Sie die Benutzerdokumentation.

Copyright Fujitsu Technology Solutions, 2009